

MCCRANN CYRUS MFG

Quality Products and Services since 1977

3M 8850 Specifications

Product Description: The product is a looped-pile, carpet-type entryway matting. 3M8850 features a unique tufted construction with random pattern design utilizing two different size fibers. Areas of large diameter polypropylene fibers combine with areas of small diameter nylon fibers to maximize dirt removal, water pick up and holding capacity. The matting has a solid vinyl backing and edging on all four sides.

Intended Use: For use as entryway matting where snow, water and/or dirt tracking is a problem.

Standard Sizes: Standard mats with 4-side edging: 2 feet x 3 feet, 3 feet x 5 feet, 3 feet x 10 feet, 4 feet x 6 feet, 4 feet x 8 feet, 4 feet x 10 feet and 6 feet x 10 feet (0.6m x 0.9m, 0.9m x 1.5m, 0.9m x 3.0m, 1.2m x 1.8m, 1.2 x 2.4m 1.2m x 3.0m and 1.8m x 3.0m)

Custom lengths with 4-side edging: Widths: 3 feet, 4 feet or 6 feet

Lengths: 2 feet to 60 feet in 1-foot increments

Custom cuts with 4-side edging: Widths: 2 feet to 11.5 feet (0.6m to 3.5m) Lengths: 2 feet to 60 feet (0.6m to 18.2m)

Colors: Ebony, Slate (gray), Dove (brown), Checkers (gray/red mix), Blueberry, Burgundy, Spruce

Requirements: The product is made of two different sizes of fibers featuring a unique tufted construction and random pattern design; small diameter nylon fibers combined with large diameter polypropylene fibers to maximize performance. The product has a black solid vinyl backing and edging on four sides.

Detailed Requirements:

Property

Thickness ASTM D418-68
Weight ASTM D-418
Flammability DOC FF 1-70 (Pill Test)

Typical Values

Minimum: 0.32 inches (8.1 mm)
Minimum: 6.5 lb/yd² (3.5 kg/m²)
Passes

Electrostatic Propensity AATCC 134, Neolite soles Step -1.88 KV Scuff 1.38 KV

3M 8850 Warranty

Limited Warranty. 3M warrants that its 3MTM Nomad™ Entrance Matting Systems products (see below) will be free from defects in material and manufacture, and will give satisfactory performance for applications recommended in 3M's literature for the period indicated below from date of purchase from 3M's authorized distributor. 3M shall not be liable for any injury, loss or damage, direct, indirect, incidental, special or consequential arising out of the use of the matting. User is otherwise responsible for determining whether the product is fit for a particular purpose and suitable for user's application. This warranty will not apply to damage incurred as a result of abuse or misuse (e.g., burns, cuts, or tears) or because of failure to properly install, clean or maintain the product. If this 3M product is defective within the stated warranty period, user must notify 3M's authorized distributor and supply a dated, paid invoice for the product. Users exclusive remedy and 3M's sole

obligation shall be, at 3M's option, to replace or refund the purchase price of the product based on the following schedule. Replacement or refund is one time only. Warranty time begins upon the date of the original purchase invoice.

Limitation of Liability. Except where prohibited by law, 3M will not be liable for any loss or damage arising from this 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability. This warranty gives you specific legal rights, and you may have other rights which vary from state to state, or country to country.

WARRANTY PERIOD: 1 year replacement; 1-2 years 50% off replacement matting

3M 8850 Cleaning and Maintenance

Daily Maintenance: Vacuum daily. Use an upright beater-brush dry vacuum adjusted to its most powerful setting. Move nozzle slowly over mat to allow time for dirt to be picked up.

In heavier traffic areas or at pivot points, rotate matting end for end when repositioning.

Important: Keeping the backing of the mat clean is critical in minimizing the mat "walking". Floor under mat must also be kept clean (swept and/or damp mopped underneath mat).

Weekly Maintenance:

1. Remove matting from service.
2. Turn matting over and run beater bar, dry vacuum on back side of matting.
3. Pick up matting.
4. Clean up dirt/debris from floor (sweep, vacuum, damp mop, etc.)
5. Place matting back in service and vacuum top surface of matting.

Wet Conditions for Mats and Rolls:

1. Use an extractor or wet vacuum to remove as much water as possible from mat.
2. Allow mat to dry. Hang up if necessary. Use of fan or blower will reduce dry time.

Restorative Maintenance:

Frequency of restorative maintenance will depend on the amount of traffic and soil in the area of application.

1. Wet matting with diluted solution of 3M! Carpet Pretreatment or 3M! Carpet Extraction Cleaner.
2. Loosen dirt using a rotary brush.
3. Extract at least two times. (If heavily soiled, repeating this procedure may be required.)
4. Let mat dry.

High Pressure Washer

Use high pressure washer (i.e., at self-service car wash).

1. Hang mat up.
2. Wash mat thoroughly.
3. Rinse mat thoroughly.
4. Let mat dry.